


## TITAN 1911 Pistol 45 ACP Exploded View



Ref #	Name
42	Plunger Pin Short
43	Front Sight, Dovetail
44	Rear Sight, Novak
45	Guide Plate
46	Grip
46a	Grip
47	Grip Screw Male
48	Grip Screw Female
49	Trigger
50	Guide Plate Screw
51	Recoil Spring 2

Ref #	Name	
1	Barrel	
2	Secondary Plug	
3	Barrel Link	
4	Barrel Link Pin	
5	Disconnector	
6	Ejector	
7	Ejector Pin	
8	Extractor	
9	Firing Pin	
10	Firing Pin Spring	
11	Firing Pin Stop	
12	Frame	
13	Safety Grip, Beavertail	
14	Hammer, Round	
15	Hammer Pin	
16	Hammer Strut	
17	Hammer Strut Pin	
18	Magazine Assembly	
19	Magazine Follower	
20	Magazine Spring	
21	Magazine Catch	
22	Magazine Catch Lock	
23	Magazine Catch Spring	
24	Main Spring	
25	Retainer Cap	
26	Follower Housing Pin	
27	Main Spring Housing	
28	Housing Pin	
29	Retainer Guide	
30	Plunger Tube	
31	Plunger Spring	
32	Recoil Spring 1	
33	Reverse Plug	
34	Recoil Spring Guide	
35	Safety Lock	
36	Plunger Pin Long	
37	Sear	
38	Sear Pin	
39	Sear Spring	
40	Slide	
41	Slide Stop	